

2004	Volvo	NH12 420 4x2	D12D420	600 ± 50	2070 ± 50	1,10	1,49	87+3 / 1800	
2004	Volvo	NH12 420 6x2							
2004	Volvo	NH12 420 6x4							
2004	Volvo	NH12 460 4x2	D12D460	600 ± 50	2070 ± 50	1,10	1,49	87+3 / 1800	
2004	Volvo	NH12 460 6x2							
2004	Volvo	NH12 460 6x4							
2004	Volvo	VM17 210 4x2	MWM6.10TCA206	700 ± 50	2900 ± 50	1,59	2,15	89+3 / 2400	
2004	Volvo	VM23 210 6x2							
2004	Volvo	VM17 240 4x2	MWM6.10TCA240	700 ± 50	2900 ± 50	1,59	2,15	95+3 / 2400	
2004	Volvo	VM23 240 6x2							
2005	Volvo	FM12 340 4x2	D12D340	600 ± 50	2070 ± 50	1,10	1,49	88+3 / 1800	
2005	Volvo	FM12 340 6x4							
2005	Volvo	FM12 340 8x4							
2005	Volvo	FM12 380 4x2	D12D380	600 ± 50	2070 ± 50	1,10	1,49	90+3 / 1800	
2005	Volvo	FM12 380 6x4							
2005	Volvo	FM12 380 8x4							
2005	Volvo	FM12 420 4x2	D12D420	600 ± 50	2070 ± 50	1,10	1,49	90+3 / 1800	
2005	Volvo	FM12 420 6x4							
2005	Volvo	FM12 420 8x4							
2005	Volvo	FM12 460 4x2	D12D460	600 ± 50	2070 ± 50	1,10	1,49	90+3 / 1800	
2005	Volvo	FM12 460 6x2							
2005	Volvo	FM12 460 8x4							
2005	Volvo	FH12 340 4x2	D12D340	600 ± 50	2070 ± 50	1,10	1,49	91+3 / 1800	
2005	Volvo	FH12 340 6x2							
2005	Volvo	FH12 340 6x4							
2005	Volvo	FH12 380 4x2	D12D380	600 ± 50	2070 ± 50	1,10	1,49	91+3 / 1800	
2005	Volvo	FH12 380 6x2							
2005	Volvo	FH12 380 6x4							
2005	Volvo	FH12 420 4x2	D12D420	600 ± 50	2070 ± 50	1,10	1,49	92+3 / 1800	
2005	Volvo	FH12 420 6x2							
2005	Volvo	FH12 420 6x4							
2005	Volvo	FH12 460 4x2	D12D460	600 ± 50	2070 ± 50	1,10	1,49	91+3 / 1800	
2005	Volvo	FH12 460 6x2							
2005	Volvo	FH12 460 6x4							
2005	Volvo	NH12 340 4x2	D12D340	600 ± 50	2070 ± 50	1,10	1,49	93+3 / 1800	
2005	Volvo	NH12 340 6x2							
2005	Volvo	NH12 340 6x4							
2005	Volvo	NH12 380 4x2	D12D380	600 ± 50	2070 ± 50	1,10	1,49	88+3 / 1800	
2005	Volvo	NH12 380 6x2							
2005	Volvo	NH12 380 6x4							
2005	Volvo	NH12 420 4x2	D12D420	600 ± 50	2070 ± 50	1,10	1,49	87+3 / 1800	
2005	Volvo	NH12 420 6x2							
2005	Volvo	NH12 420 6x4							